



**JRC WEB ACCESSORIES**

46 PASSAIC AVENUE  
FAIRFIELD, NEW JERSEY 07004  
(973) 625-3888  
FAX (973) 226-4249

## JRC QUICK LOCKING MECHANICAL CHUCK

*Adding Shims to accommodate oversize cores*

Please refer to drawing # B-3173

1. With Phillips head screwdriver, remove flat head screws in **retainer-gripper**.
2. Remove **retainer-gripper, spring, gripper and step plate**.
3. Cut three pieces 0.005" thick shim to fit between **step plate** and **pad-rubber**.
4. Re-assemble and test. If too loose, add more shims in increments of 0.005" thick.

Add and subtract sets of three shims at a time. Adding only one shim will result in a non-concentric core.